

Installing your Stick

There are two ways to install Stick. For both ways we have included mounting materials.

With 30 mm bolts and the integrated nuts

Size 1

Drill a hole of 5 mm. You can align holes using a tape measure if you are placing more than more one Stick at the same height.

Size 2 and 3

Drill two holes, horizontally or vertically, to mount Stick. The drill size is 5 mm. Use a tape measure to align the drill holes.

Center-to-center distance between the drill holes is:

size 2 90 mm

size 3 190 mm

Place your grip and attach it using the two included mounting bolts.

Please pay attention to the following: special nuts are integrated in Stick which secure themselves when a screw is applied. This needs to be done very precisely. The included bolts of 30 mm are suitable for 15-18 mm thick doors.

With screws

Size 1

Mark the desired location of Stick. You can align the drill holes using a tape measure if you are placing more than more one Stick at the same height.

Size 2 and 3

Pre-drill two holes, horizontally or vertically, to mount Stick. Use a tape measure to align the drill holes.

Place your grip and attach it using the two included mounting screws.

Please pay attention to the following: If the screws become a bit loose while using Stick, please tighten the screws for securing Stick. This way you prevent the drilling holes getting wider.

Enjoy your new handles!

If you have any questions about the installation, please don't hesitate to contact us at order@designstudionu.nl

Best wishes,

Tessa Weerdenburg & Nathalie Fransen

Design Studio Nu