

Installing your Stick

With screws

Size 1

Pre-drill a hole at the desired location. You can align the drill holes using a tape measure if you are placing more than more one Stick at the same height.

Size 2, 3 and 4

Pre-drill two holes, horizontally or vertically, to mount Stick. Use a tape measure to align the drill holes.

The center-to-center distance between the drill holes is:

size 2 32 mm

size 3 128 mm

size 4 192 mm

Place your grip and attach it using the included mounting screws.

Please pay attention to the following: If the screws become a bit loose while using Stick, please tighten the screws for securing Stick. This way you prevent the drilling holes getting wider.

Enjoy your new grips!

If you have any questions about the installation, please don't hesitate to contact us at order@designstudionu.nl

Best wishes,

Design Studio Nu